



Posizioni di montaggio

Mounting positions

Einbaulagen

Positions de montage

(C05)

V 0.25 - V 0.5

V 1 - V 2

B3		<table border="1"> <tr> <td>V 0.25 F</td> <td>0.14</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 F</td> <td>0.18</td> </tr> <tr> <td>V 0.25 U₋ / VR 0.25₋</td> <td>0.12</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 U₋ / VR 0.5₋</td> <td>0.15</td> </tr> <tr> <td>VD 0.5 U₋ / VRD 0.5</td> <td>0.30</td> <td> </td> </tr> </table> <p>Oil Donax TX (for life)</p>	V 0.25 F	0.14		V 0.5 F	0.18	V 0.25 U ₋ / VR 0.25 ₋	0.12		V 0.5 U ₋ / VR 0.5 ₋	0.15	VD 0.5 U ₋ / VRD 0.5	0.30			<table border="1"> <tr> <td>V 1 F</td> <td>0.30</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 F</td> <td>0.40</td> </tr> <tr> <td>V 1 U₋ / VR 1₋</td> <td>0.25</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 U₋ / VR 2₋</td> <td>0.32</td> </tr> <tr> <td>VD 1 U₋ / VRD 1</td> <td>0.35</td> <td rowspan="2"> </td> </tr> <tr> <td>VD 2 U₋ / VRD 2</td> <td>0.46</td> </tr> </table> <p>Oil Donax TA (2000-3000 hrs.)</p>	V 1 F	0.30		V 2 F	0.40	V 1 U ₋ / VR 1 ₋	0.25		V 2 U ₋ / VR 2 ₋	0.32	VD 1 U ₋ / VRD 1	0.35		VD 2 U ₋ / VRD 2	0.46
		V 0.25 F	0.14																													
V 0.5 F	0.18																															
V 0.25 U ₋ / VR 0.25 ₋	0.12																															
V 0.5 U ₋ / VR 0.5 ₋	0.15																															
VD 0.5 U ₋ / VRD 0.5	0.30																															
V 1 F	0.30																															
V 2 F	0.40																															
V 1 U ₋ / VR 1 ₋	0.25																															
V 2 U ₋ / VR 2 ₋	0.32																															
VD 1 U ₋ / VRD 1	0.35																															
VD 2 U ₋ / VRD 2	0.46																															
B6		<table border="1"> <tr> <td>V 0.25 F</td> <td>0.14</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 F</td> <td>0.18</td> </tr> <tr> <td>V 0.25 U₋ / VR 0.25₋</td> <td>0.12</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 U₋ / VR 0.5₋</td> <td>0.15</td> </tr> <tr> <td>VD 0.5 U₋ / VRD 0.5</td> <td>0.30</td> <td> </td> </tr> </table> <p>Oil Donax TX (for life)</p>	V 0.25 F	0.14		V 0.5 F	0.18	V 0.25 U ₋ / VR 0.25 ₋	0.12		V 0.5 U ₋ / VR 0.5 ₋	0.15	VD 0.5 U ₋ / VRD 0.5	0.30			<table border="1"> <tr> <td>V 1 F</td> <td>0.30</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 F</td> <td>0.40</td> </tr> <tr> <td>V 1 U₋ / VR 1₋</td> <td>0.25</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 U₋ / VR 2₋</td> <td>0.32</td> </tr> <tr> <td>VD 1 U₋ / VRD 1</td> <td>0.35</td> <td rowspan="2"> </td> </tr> <tr> <td>VD 2 U₋ / VRD 2</td> <td>0.46</td> </tr> </table> <p>Oil Donax TA (2000-3000 hrs.)</p>	V 1 F	0.30		V 2 F	0.40	V 1 U ₋ / VR 1 ₋	0.25		V 2 U ₋ / VR 2 ₋	0.32	VD 1 U ₋ / VRD 1	0.35		VD 2 U ₋ / VRD 2	0.46
		V 0.25 F	0.14																													
V 0.5 F	0.18																															
V 0.25 U ₋ / VR 0.25 ₋	0.12																															
V 0.5 U ₋ / VR 0.5 ₋	0.15																															
VD 0.5 U ₋ / VRD 0.5	0.30																															
V 1 F	0.30																															
V 2 F	0.40																															
V 1 U ₋ / VR 1 ₋	0.25																															
V 2 U ₋ / VR 2 ₋	0.32																															
VD 1 U ₋ / VRD 1	0.35																															
VD 2 U ₋ / VRD 2	0.46																															
B7		<table border="1"> <tr> <td>V 0.25 F</td> <td>0.14</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 F</td> <td>0.18</td> </tr> <tr> <td>V 0.25 U₋ / VR 0.25₋</td> <td>0.12</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 U₋ / VR 0.5₋</td> <td>0.15</td> </tr> <tr> <td>VD 0.5 U₋ / VRD 0.5</td> <td>0.30</td> <td> </td> </tr> </table> <p>Oil Donax TX (for life)</p>	V 0.25 F	0.14		V 0.5 F	0.18	V 0.25 U ₋ / VR 0.25 ₋	0.12		V 0.5 U ₋ / VR 0.5 ₋	0.15	VD 0.5 U ₋ / VRD 0.5	0.30			<table border="1"> <tr> <td>V 1 F</td> <td>0.30</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 F</td> <td>0.40</td> </tr> <tr> <td>V 1 U₋ / VR 1₋</td> <td>0.25</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 U₋ / VR 2₋</td> <td>0.32</td> </tr> <tr> <td>VD 1 U₋ / VRD 1</td> <td>0.35</td> <td rowspan="2"> </td> </tr> <tr> <td>VD 2 U₋ / VRD 2</td> <td>0.46</td> </tr> </table> <p>Oil Donax TA (2000-3000 hrs.)</p>	V 1 F	0.30		V 2 F	0.40	V 1 U ₋ / VR 1 ₋	0.25		V 2 U ₋ / VR 2 ₋	0.32	VD 1 U ₋ / VRD 1	0.35		VD 2 U ₋ / VRD 2	0.46
		V 0.25 F	0.14																													
V 0.5 F	0.18																															
V 0.25 U ₋ / VR 0.25 ₋	0.12																															
V 0.5 U ₋ / VR 0.5 ₋	0.15																															
VD 0.5 U ₋ / VRD 0.5	0.30																															
V 1 F	0.30																															
V 2 F	0.40																															
V 1 U ₋ / VR 1 ₋	0.25																															
V 2 U ₋ / VR 2 ₋	0.32																															
VD 1 U ₋ / VRD 1	0.35																															
VD 2 U ₋ / VRD 2	0.46																															
B8		<table border="1"> <tr> <td>V 0.25 F</td> <td>0.14</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 F</td> <td>0.18</td> </tr> <tr> <td>V 0.25 U₋ / VR 0.25₋</td> <td>0.12</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 U₋ / VR 0.5₋</td> <td>0.15</td> </tr> <tr> <td>VD 0.5 U₋ / VRD 0.5</td> <td>0.30</td> <td> </td> </tr> </table> <p>Oil Donax TX (for life)</p>	V 0.25 F	0.14		V 0.5 F	0.18	V 0.25 U ₋ / VR 0.25 ₋	0.12		V 0.5 U ₋ / VR 0.5 ₋	0.15	VD 0.5 U ₋ / VRD 0.5	0.30			<table border="1"> <tr> <td>V 1 F</td> <td>0.30</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 F</td> <td>0.40</td> </tr> <tr> <td>V 1 U₋ / VR 1₋</td> <td>0.25</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 U₋ / VR 2₋</td> <td>0.32</td> </tr> <tr> <td>VD 1 U₋ / VRD 1</td> <td>0.35</td> <td rowspan="2"> </td> </tr> <tr> <td>VD 2 U₋ / VRD 2</td> <td>0.46</td> </tr> </table> <p>Oil Donax TA (2000-3000 hrs.)</p>	V 1 F	0.30		V 2 F	0.40	V 1 U ₋ / VR 1 ₋	0.25		V 2 U ₋ / VR 2 ₋	0.32	VD 1 U ₋ / VRD 1	0.35		VD 2 U ₋ / VRD 2	0.46
		V 0.25 F	0.14																													
V 0.5 F	0.18																															
V 0.25 U ₋ / VR 0.25 ₋	0.12																															
V 0.5 U ₋ / VR 0.5 ₋	0.15																															
VD 0.5 U ₋ / VRD 0.5	0.30																															
V 1 F	0.30																															
V 2 F	0.40																															
V 1 U ₋ / VR 1 ₋	0.25																															
V 2 U ₋ / VR 2 ₋	0.32																															
VD 1 U ₋ / VRD 1	0.35																															
VD 2 U ₋ / VRD 2	0.46																															
V5		<table border="1"> <tr> <td>V 0.25 F</td> <td>0.28</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 F</td> <td>0.30</td> </tr> <tr> <td>V 0.25 U₋ / VR 0.25₋</td> <td>0.22</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 U₋ / VR 0.5₋</td> <td>0.27</td> </tr> <tr> <td>VD 0.5 U₋ / VRD 0.5</td> <td>0.70</td> <td> </td> </tr> </table> <p>Oil Donax TX (for life)</p>	V 0.25 F	0.28		V 0.5 F	0.30	V 0.25 U ₋ / VR 0.25 ₋	0.22		V 0.5 U ₋ / VR 0.5 ₋	0.27	VD 0.5 U ₋ / VRD 0.5	0.70			<table border="1"> <tr> <td>V 1 F</td> <td>0.58</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 F</td> <td>0.78</td> </tr> <tr> <td>V 1 U₋ / VR 1₋</td> <td>0.40</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 U₋ / VR 2₋</td> <td>0.54</td> </tr> <tr> <td>VD 1 U₋ / VRD 1</td> <td>1.00</td> <td rowspan="2"> </td> </tr> <tr> <td>VD 2 U₋ / VRD 2</td> <td>1.5</td> </tr> </table> <p>Oil Donax TA (2000-3000 hrs.)</p>	V 1 F	0.58		V 2 F	0.78	V 1 U ₋ / VR 1 ₋	0.40		V 2 U ₋ / VR 2 ₋	0.54	VD 1 U ₋ / VRD 1	1.00		VD 2 U ₋ / VRD 2	1.5
		V 0.25 F	0.28																													
V 0.5 F	0.30																															
V 0.25 U ₋ / VR 0.25 ₋	0.22																															
V 0.5 U ₋ / VR 0.5 ₋	0.27																															
VD 0.5 U ₋ / VRD 0.5	0.70																															
V 1 F	0.58																															
V 2 F	0.78																															
V 1 U ₋ / VR 1 ₋	0.40																															
V 2 U ₋ / VR 2 ₋	0.54																															
VD 1 U ₋ / VRD 1	1.00																															
VD 2 U ₋ / VRD 2	1.5																															
V6		<table border="1"> <tr> <td>V 0.25 F</td> <td>0.14</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 F</td> <td>0.18</td> </tr> <tr> <td>V 0.25 U₋ / VR 0.25₋</td> <td>0.12</td> <td rowspan="2"> </td> </tr> <tr> <td>V 0.5 U₋ / VR 0.5₋</td> <td>0.15</td> </tr> <tr> <td>VD 0.5 U₋ / VRD 0.5</td> <td>0.40</td> <td> </td> </tr> </table> <p>Oil Donax TX (for life)</p>	V 0.25 F	0.14		V 0.5 F	0.18	V 0.25 U ₋ / VR 0.25 ₋	0.12		V 0.5 U ₋ / VR 0.5 ₋	0.15	VD 0.5 U ₋ / VRD 0.5	0.40			<table border="1"> <tr> <td>V 1 F</td> <td>0.30</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 F</td> <td>0.40</td> </tr> <tr> <td>V 1 U₋ / VR 1₋</td> <td>0.25</td> <td rowspan="2"> </td> </tr> <tr> <td>V 2 U₋ / VR 2₋</td> <td>0.32</td> </tr> <tr> <td>VD 1 U₋ / VRD 1</td> <td>0.50</td> <td rowspan="2"> </td> </tr> <tr> <td>VD 2 U₋ / VRD 2</td> <td>0.70</td> </tr> </table> <p>Oil Donax TA (2000-3000 hrs.)</p>	V 1 F	0.30		V 2 F	0.40	V 1 U ₋ / VR 1 ₋	0.25		V 2 U ₋ / VR 2 ₋	0.32	VD 1 U ₋ / VRD 1	0.50		VD 2 U ₋ / VRD 2	0.70
		V 0.25 F	0.14																													
V 0.5 F	0.18																															
V 0.25 U ₋ / VR 0.25 ₋	0.12																															
V 0.5 U ₋ / VR 0.5 ₋	0.15																															
VD 0.5 U ₋ / VRD 0.5	0.40																															
V 1 F	0.30																															
V 2 F	0.40																															
V 1 U ₋ / VR 1 ₋	0.25																															
V 2 U ₋ / VR 2 ₋	0.32																															
VD 1 U ₋ / VRD 1	0.50																															
VD 2 U ₋ / VRD 2	0.70																															

Tappo di sfogo
 Breather plug
 Entlüftungstopfen
 Bouchon d'évent

Tappo di carico
 Filler plug
 Einfüllstopfen
 Bouchon de remplissage

Tappo di scarico
 Drain plug
 Ablassstopfen
 Bouchon de vidange

Tappo di livello
 Level plug
 Ölstandstopfen
 Bouchon de niveau

Raccordo orientabile 90° elbow
 90° Winkel
 Raccord coudé



Posizioni di montaggio

Mounting positions

Einbaulagen


Positions de montage

(C06)

V 3 - V 5.5


V 10

B3



V 3 F - V 5.5 F_	0.70
V 3 U_ / VR 3 V 5.5 U_ / VR 5.5	1.0
VD 3 F VD 5.5 F	1.3
VD 3 U_ / VRD 3 U_	1.6
VD 5.5 U_ / VRD 5.5 U_	1.6


Oil Donax TA (2000-3000 hrs.)



V 10 F V 10 U_ / VR 10	1.8
VD 10 F VD 10 U_ / VRD 10 U_	2.0


Oil Donax TA (2000-3000 hrs.)

B6



V 3 F - V 5.5 F_	0.90
V 3 U_ / VR 3 V 5.5 U_ / VR 5.5	1.0
VD 3 F VD 5.5 F	1.3
VD 3 U_ / VRD 3 U_	1.6
VD 5.5 U_ / VRD 5.5 U_	1.6


Oil Donax TA (2000-3000 hrs.)



V 10 F V 10 U_ / VR 10	1.8
VD 10 F VD 10 U_ / VRD 10 U_	2.0


Oil Donax TA (2000-3000 hrs.)

B7



V 3 F - V 5.5 F_	0.90
V 3 U_ / VR 3 V 5.5 U_ / VR 5.5	1.0
VD 3 F VD 5.5 F	1.3
VD 3 U_ / VRD 3 U_	1.6
VD 5.5 U_ / VRD 5.5 U_	1.6


Oil Donax TA (2000-3000 hrs.)



V 10 F V 10 U_ / VR 10	1.8
VD 10 F VD 10 U_ / VRD 10 U_	2.0


Oil Donax TA (2000-3000 hrs.)

B8



V 3 F - V 5.5 F_	1.0
V 3 U_ / VR 3 V 5.5 U_ / VR 5.5	1.3
VD 3 F VD 5.5 F	1.6
VD 3 U_ / VRD 3 U_	1.9
VD 5.5 U_ / VRD 5.5 U_	1.9


Oil Donax TA (2000-3000 hrs.)



V 10 F V 10 U_ / VR 10	2.1
VD 10 F VD 10 U_ / VRD 10 U_	2.1

Oil Donax TA (2000-3000 hrs.)

V5




V 3 F - V 5.5 F_	2.1
V 3 U_ / VR 3 V 5.5 U_ / VR 5.5	2.0

Oil Donax TA (2000-3000 hrs.)

VD 3 F VD 5.5 F	4.5
VD 3 U_ / VRD 3 U_	4.8
VD 5.5 U_ / VRD 5.5 U_	4.8

Oil Donax TA (2000-3000 hrs.)




V 10 F V 10 U_ / VR 10	3.2
---------------------------	-----

Oil Donax TA (2000-3000 hrs.)

VD 10 F VD 10 U_ / VRD 10	8.5
------------------------------	-----

Oil Donax TA (2000-3000 hrs.)

V6




V 3 F - V 5.5 F_	1.0
V 3 U_ / VR 3 V 5.5 U_ / VR 5.5	1.3

Oil Donax TA (2000-3000 hrs.)

VD 3 F VD 5.5 F	2.8
VD 3 U_ / VRD 3 U_	3.0
VD 5.5 U_ / VRD 5.5 U_	3.0

Oil Donax TA (2000-3000 hrs.)



V 10 F V 10 U_ / VR 10	2.8
---------------------------	-----

Oil Donax TA (2000-3000 hrs.)

VD 10 F VD 10 U_ / VRD 10	7.0
------------------------------	-----

Oil Donax TA (2000-3000 hrs.)